



Serving the New Jersey & New York areas since 1972

VACUUM PROCEDURES

Directions:

1. Attach appropriate end of vacuum hose to the vacuum head and pole.
2. Place vacuum head and pole in water.
3. Attach other end of hose to skim vac.
4. Hold skim vac over a return in pool to fill hose with water. **Note:** You will know the hose is full when bubbles from opposite end of hose, in pool, stop.
5. Place skim vac in skimmer you choose to use.
6. For best suction, turn off all other valves, other than skimmer you are using.
Note: If there is too much suction, partially open one other valve.
7. When done vacuuming open all other valves.
8. With all valves open, you should be able to remove skim vac from skimmer. If suction is too strong, simply turn off the skimmer in use to release suction. Remove the skim vac and immediately turn skimmer back on.